

Clip Sonic[®]

TECHNOLOGY

Instruction Manual

Compatible Bluetooth[®] handsfree car kit



Reference : TEC585
Version : 1.3
Language : English

Clip Sonic[®]

TECHNOLOGY

Instruction Manual

Thank you for buying our CLIP SONIC product.

We take great care in design, ergonomics and ease of use of our products. We hope that this product will give you complete satisfaction.

This instruction manual is also available on our website www.clipsonic.com


1. Introduction

Congratulations on choosing TEC585 Sunvisor Bluetooth[®] Handsfree Car kit. Please read manual very carefully so that you can operate all features and functions to get the best performance. The unit is specially designed to you

2. Caution

- a. Please do not use or store the unit in high temperature or hazardous location:
- b. Please do not expose the unit to rain.
- c. Please do not disassemble, repair or modify the unit
- d. The unit comes with a rechargeable battery so please do not throw or put in fire to avoid explosion
- e. Please take out battery if the device is not going to be used for a long time.
- f. Low battery power may result in reduction in bluetooth[®] transmission distance or disconnection.

3. Product Diagram



Clip Sonic®

TECHNOLOGY

Instruction Manual

4. Operating the car Bluetooth speaker

A. ON/OFF:

Voice report of “Power On” and “Power Off” will be offered when press the ON/OFF key.

B. Bluetooth® Pairing:

If the unit has never been paired with a Bluetooth® device before, you need to follow the instructions below to pair the car speaker with your Bluetooth® device.

- 1) When the speaker is ready to pair with your Bluetooth device in the first time, Blue LED indicator flash fast
- 2). Activate Bluetooth® on your compatible device and set it to search for compatible devices.
- 3). Select “TEC585” from the list of found devices and then you will hear the voice prompt “pairing completed”
Note: If the unit is already connected to another Bluetooth® device then the speaker will not appear in search list and you need to disconnect the already paired Bluetooth® device from the speaker and search again.
- 4). If your device asks for a passkey, enter digits “0000” and press “OK”.(Varies depending on the Bluetooth® device manufacturers, model and software version)
- 5). If the pairing is successful, you will hear “beep” sound, the speaker will have Voice Prompt “connected` and the Blue LED indicator will flash slowly and your speaker is ready to receive calls from mobile or play the music wirelessly.

Note: If the speaker has been paired to the Bluetooth® device before you need to follow the pairing instructions below to connect the speaker to the Bluetooth® device:

Activate Bluetooth® on your compatible device and put the speaker on “Bluetooth Mode” and the speaker will connect automatically to the compatible device and you will hear a Voice Prompt “connected”.

6) Pair the second phone

The unit allow to pair two Bluetooth enabled phones device at the same time. Please refer the follow Steps to pairing:

- a) Turn off your mobile phone’s Bluetooth function or disconnect the Bluetooth connection.
- b) Please pairing for the second cellphone as the above steps. After the second cellphone pairing successfully and with voice prompt `pairing completed, connected`, then please connected the first phone. And now the two phones pairing at the same time.

5. Bluetooth in Car Speakerphone Operation

(1)Answer a call

When comes a call, Bluetooth in car speakerphone will ring and report voice of “incoming call”, press answer key to answer.

Remark: The voice prompt “incoming call” is available for Android mobile phones, iPhone has no voice prompt “incoming call”

(2)Hang up a call

Press answer key to hang up it during a call.

(3)Redial last number

Short press the answer key twice when the Bluetooth in-car speakerphone is on and not in use, you can call the last number you dialed.

(4)Volume Control

Clip Sonic[®]

TECHNOLOGY

Instruction Manual

Short press volume- (-) or volume+ (+) to adjust volume.

(5) Play music

In standby mode, short press the Bluetooth in-car speakerphone answer key, start playing mobile phone inside the music; Long press “+” or “-” to change the “next” and the “previous” music.

REMARKS: When unit is on no working status, no connect Bluetooth, then it will auto-off after 10 minutes.

(6) Car speaker and mobile headset transformation

When the conversation is in progress via the car speaker, short press the ANSWER key for twice then the conversation will be switched to mobile phone, short press the ANSWER key again, the conversation will be switched back to car speaker unit again.

Remarks: This function is not available for all Bluetooth enabled device, it depends on the compatibility of the paired device.

6. The Bluetooth Speakerphone put in the car

Bluetooth in Car Speakerphone requires no installation and can be easily caught in the car sun visor.

7. Car Speaker Charging

This device is with rechargeable battery. During the charging, When unit is at `OFF` status, the LED indicator will be RED on; When unit is at `ON` status, then LED indicator will be RED on and Blue LED will flash on every 3 seconds; When full charged, the LED light will turn off. It's strongly recommended to make it fully charged before using. Normal full charging time is approx. 2 hrs.

Important Notice:

(1) The charging LED indicator will have a short delay, if the Bluetooth in car speakerphone is long-time non-occupied or power run out.

(2) In order to extend durability of battery and ensure the stability of speakerphone's performance, it's recommended to charge the speakerphone immediately whenever low battery appeared, the LED indicator flash every 3 seconds in red color battery durability, device stand-by time will be shorter if the device is still used in case of low-battery, also, charging time will be more hours than usual. Meanwhile, it will shut down automatically soon under a very low battery condition.

(3) While charging, the LED indicator will always light up in red color, and will put out after charging complete.

8. Device Self-protection and Low-power

When battery power is less than 3.3v, voice prompt “battery low” and device turn off automatically when less than 3.0v.

9. Compatibility

Wireless: With BLUETOOTH[®] V3.0, HFPV1.5, A2DPV1.2, AVRCPV1.4, HSP1.2, GAVDP1.2, IOP

Product features:

Model no : TEC585

Bluetooth version: BLUETOOTH[®] V3.0+EDR

Transmission distance : ≤8-10M (This may vary according to environment and connected Bluetooth device)

Clip Sonic[®]

TECHNOLOGY

Instruction Manual

Charge input : DC 5V 400mA

Build-in Rechargeable Battery: 3.7V 400mAh

Frequency : 2.4GHZ-2.480GHZ

Charge time: 1.5-2 Hours

Talking time: 6-8 Hours

Standby time: 20 days

8. Components

1. Unit: 1pc
2. USB power cable: 1pc
3. Manual : 1pc
4. Giftbox 1pc

10. Trouble Shooting Guide

Should you experience any difficulty while using the car speaker? Please refer to the following Chart.

Fault	Reason	Solution
Not Charging	The Car charger (not including) is not plugged well or the USB cable (included) is not plugged into the micro USB jack behind the speaker.	Plug the car charger (not including) into cigarette lighter socket well and plug the USB cable (included) into the micro USB jack of the speaker.
	Car cigarette socket is no function	Plug another device into the same socket to confirm the socket is working.
	Computer USB port is not function.	Make sure your computer power is turned on and try another USB port.
No Sound	The battery is dead.	Recharge the unit
	The car speaker is not linked to the cell phone.	Go through "Car Speaker Operations" process to connect the speaker.
	Volume set is too low.	Increase the volume of your device.
No Audio Signal via Bluetooth Connection	Speaker is not paired to the audio source.	Check whether a connection exists. If necessary pair the speaker again to the audio source
	Volume too low	Increase the volume on the speaker
		Increase the volume on the audio source.
Car Speaker cannot be Connected	Pairing does not work	Check whether the audio source supports the A2DP protocol
	Audio source is switched off	Switch on the audio source
	Bluetooth is switched off at the audio source.	Switch on the Bluetooth function in the audio source.
	Bluetooth version is not supported.	Use a different playback unit.
Poor Sound quality from a Bluetooth device	Bluetooth device is almost out of range of the speaker	Move your Bluetooth device closer to the speaker

Clip Sonic®

TECHNOLOGY

Instruction Manual



Correct disposal of the unit
(Electrical and Electronic Equipment)

(Applicable in the European Union and the rest of Europe that have adopted separate collection systems countries)

The European Directive 2012/19/UE on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed of in the normal household waste stream. Old appliances must be collected separately in order to optimize the recovery and recycling of the materials they contain and reduce the impact on human health and the environment. The symbol of the crossed out dustbin is marked on all products to remind the obligations of separate collection. Consumers should contact their local authority or retailer for information concerning the correct disposal of their product.

CE



Pour en savoir plus :
www.quefairedemesdechets.fr

CLIP SONIC

BP 61071

67452 Mundolsheim

- Photo no contractual
- Worried about the quality of his products the manufacturer reserves the right to make modifications without advance notice